

dig*i*ETUI

# Kamera sucht Tasche

Taschengrößen-Übersicht für Kameras



**S+M** REHBERG

DIGITAL+PHOTO+MORE

[www.digiETUI.de](http://www.digiETUI.de)



Canon A1000	H2/A3	Casio EX-FC100	H2	Fuji Fine Pix S9600	S1
Canon A1100 is	A2,H2	Casio EX-FH100	T2/H4/A4	Fuji Fine Pix Z10	H1/A1/H0
Canon A3000	H2	Casio EX-FS10	H0,T1	Fuji Fine Pix Z100 FD	H1/T1
Canon A3100	H2	Casio EX-H10	A2,T2	Fuji Fine Pix Z2	H1/A1/H0
Canon A470	H3/A4	Casio EX-H15	T2/H4/A4	Fuji Fine Pix Z20FD	A1/T1/H1
Canon A550	A2//H4	Casio EX-S12	H0,T1	Fuji Fine Pix Z3	H1/A1/H0
Canon A560	A2/H4	Casio EX-Z 19	H0	Fuji Fine Pix Z30	A1,T1
Canon A580 is	A2	Casio EX-Z 29	T1	Fuji Fine Pix Z300	T1/H0/A1
Canon A590 is	A2	Casio EX-Z 330	T1	Fuji Fine Pix Z300	H1
Canon A650	H4	Casio EX-Z2000	H2	Fuji Fine Pix Z33WP	H1,A1,T1
Canon A700	H4/A2	Casio EX-Z250	H0	Fuji Fine Pix Z5FD	H0/T1
Canon A720	H4/A2	Casio EX-Z270	H0/A1/T1	Fuji Fine Pix Z70	T1/H0/A1
Canon A90	T1/H2/A3	Casio EX-Z29	A3/H2/T1	Fuji Fine Pix Z700	H0/T1
Canon A95	T1/H2/A3	Casio EX-Z450	H2	JVC GZ MC 100	H4
Canon Digital A2100 is	A2,T2	Casio EX-Z500	H1/A1	Kodak C 1013	A2
Canon Digital Ixus 100 is	H0,A1,T1	Casio EX-Z550	T1/H2	Kodak C 913	A2
Canon Digital Ixus 105	H1/A1/T1	Casio EX-Z750	H1/A1	Kodak C160	H2
Canon Digital Ixus 110 is	H0,T1	Casio EX-Z85	H0/A1	Kodak C180	A3
Canon Digital Ixus 120	H0/A1/T1	Casio EX-Z850	H1/A1/H0	Kodak C713+C813	A2
Canon Digital Ixus 130	T1/H1/A1	Casio EX-Z90	H1/A1/T1	Kodak C743	A2
Canon Digital Ixus 200	H2/T1	Casio Hi-SPEED F1	S0/COLT2	Kodak C875	A2/T2
Canon Digital Ixus 210 is	H2/T1	Casio Hi-SPEED FH20	B2	Kodak M 1033	H0
Canon Digital Ixus 300 is	T1/A3/H2	Casio Hi-Zoom EX-V8	H0/T1/A4	Kodak M 1063	H0
Canon Digital Ixus 800 is	H1/A3	Fuji Fine Pix 3DW1	COLT0	Kodak M 1073	H0
Canon Digital Ixus 850 is	H2/T1/A3	Fuji Fine Pix F100FD	H2/A3/T1	Kodak M 1093IS	H0
Canon Digital Ixus 860 is	T1/H2/A3	Fuji Fine Pix F200 EXR	H2	Kodak M 320	H0/T1
Canon Digital Ixus 900TI	H2/T1/A3	Fuji Fine Pix F47FD	A3/H2/T1	Kodak M 340	H0/T1
Canon Digital Ixus 95	H0//A1/T1	Fuji Fine Pix F510	H4	Kodak M 380	H2
Canon Digital Ixus 950 is	T1/H2/A4	Fuji Fine Pix F610	A2	Kodak M 753	T1/H0
Canon Digital Ixus 950 TI	H2/T1/A3	Fuji Fine Pix F650	A4/T2	Kodak M 833	H0/A2
Canon Digital Ixus 960 is	T1/H2/A3	Fuji Fine Pix F70	T2/H2/A3	Kodak M 853	T1/H1
Canon Digital Ixus 970 is	T1/H2/A3	Fuji Fine Pix F70 EXR	H2/T2	Kodak M 863	H0/A1/T1
Canon Digital Ixus 980	H2	Fuji Fine Pix F700	A4	Kodak M 873	H0/A1
Canon Digital Ixus 990 is	A1,H2,T1	Fuji Fine Pix F80	T2/H4	Kodak M 883	H2
Canon EOS 1000+ 18-55	S0/Colt2	Fuji Fine Pix F810	A4/H3	Kodak M 893	H2/A3
Canon EOS 20 D+18-55	S1	Fuji Fine Pix HS10	COLT2	Kodak P 712	B2
Canon EOS 300D+18-55	S1	Fuji Fine Pix J150W	H1	Kodak P 850	B2
Canon EOS 400D+18-55	S0	Fuji Fine Pix J20	H0,A1	Kodak P 880	S0
Canon EOS 40D + 18-55	S1	Fuji Fine Pix J250	A3,H2,T1	Kodak V 803	H2
Canon EOS 450D+ 18-55	S0/Colt2	Fuji Fine Pix J50	H2	Kodak Z 1012IS	B2/COLT1
Canon EOS 550+18-135	COLT3	Fuji Fine Pix JX200	T1/H0	Kodak Z 1015IS	B1/COLT1
Canon EOS 550+18-55	S0/COLT2	Fuji Fine Pix JZ500	T1/H0	Kodak Z 1275	A2
Canon EOS 7D + 15-55	Colt3	Fuji Fine Pix LV100	T1/H0	Kodak Z 650	B1/U1
Canon Powershot -S90	H2/T2	Fuji Fine Pix S1000	B1/COLT1	Kodak Z 712is	B1
Canon PowerShot A2000	A3/H3/T2	Fuji Fine Pix S100FS		Kodak Z 740	B1
Canon PowerShot A3100is	H2	Fuji Fine Pix S1500	COLT1	Kodak Z 7590	B1
Canon PowerShot A650 is	----	Fuji Fine Pix S1800	Colt1	Kodak Z 812 IS	B1
Canon PowerShot A710 is	H4	Fuji Fine Pix S2 Pro	S1	Kodak Z 8612	B2/COLT1
Canon PowerShot A720 is	T2/A2	Fuji Fine Pix S20 Pro	B2	Kodak Z 885	A2
Canon Powershot G10	Colt0	Fuji Fine Pix S2000HD	COLT1	Kodak Z 915	T2
Canon Powershot G11	Colt0	Fuji Fine Pix S3 Pro	S1	Kodak ZD 710 HD	B1
Canon PowerShot G9	Colt0	Fuji Fine Pix S3500	B2	Kodak ZX1	A4
Canon Powershot Pro 1	B2	Fuji Fine Pix S5200EXP	S0/Colt2	Leica C-Lux 1	H1
Canon PowerShot S5 is	B2	Fuji Fine Pix S5500	B2	Leica C-Lux 2	H1
Canon PowerShot SX100 is	---	Fuji Fine Pix S5600	S0	Leica D-Lux 2	H4
Canon Powershot SX20	Colt1	Fuji Fine Pix S5700	B2	Leica D-Lux 3	T2
Canon PowerShot SX210is	T2/H4	Fuji Fine Pix S6500FD	B2	Leica Digilux 3	S1
Canon SX 200IS	H3,T2	Fuji Fine Pix S8100FD	B2/COLT1	Leica V-Lux 1	B2
Canon SX110IS	H4/T2	Fuji Fine Pix S9500	S0	Leica X1	Colt0

Nikon Coolpix L100	B1, COLT1	Olympus FE 280	H0/T1	Panasonic DMC-FX33	H1/H0/T1
Nikon Coolpix L110	B1, COLT1	Olympus FE 310	H2	Panasonic DMC-FX35	H0/A1
Nikon Coolpix L19	H2	Olympus FE 350	H2	Panasonic DMC-FX37	H2/T1/A3
Nikon Coolpix L20	H2/A3	Olympus FE 360	H0/T1	Panasonic DMC-FX40	H1,T1
Nikon Coolpix L21	T1/H2/A3	Olympus FE 370	H2/A3	Panasonic DMC-FX50	H2/A1T1
Nikon Coolpix L22	H2/A3	Olympus FE 4000	A1/H1/T1	Panasonic DMC-FX500	H2/A3
Nikon Coolpix P100	/B2	Olympus FE 4030	H0/H1/A1	Panasonic DMC-FX55	H2
Nikon Coolpix P5000	H4/A2/T2	Olympus FE 5010	H2	Panasonic DMC-FX550	H2,T1
Nikon Coolpix P5100	T2/A2	Olympus FE 5020	A1/H1/T1	Panasonic DMC-FX60	A1/H0
Nikon Coolpix P90	B2/Colt1	Olympus Mju 1010	H2	Panasonic DMC-FX66	T1/H2
Nikon Coolpix S1000PG	T2/H2	Olympus Mju 1020	H2	Panasonic DMC-FX700	h2
Nikon Coolpix S1000PJ	T2	Olympus Mju 1030 SW	H0	Panasonic DMC-FZ 100	Colt1/ B2a
Nikon Coolpix S200	H0/T1	Olympus Mju 1040	H0/H1/T1	Panasonic DMC-FZ28	COLT1
Nikon Coolpix S210	H0/A1/T1	Olympus Mju 1050 SW	H2/A3	Panasonic DMC-FZ30	S0
Nikon Coolpix S220	H1,T1	Olympus Mju 1060	H2	Panasonic DMC-FZ38	B2/Colt1
Nikon Coolpix S230	A1,H1,T1	Olympus Mju 1200	H2/T1/A3	Panasonic DMC-FZ45	colt1/B2a
Nikon Coolpix S3000	H0/T1	Olympus Mju 3000	T2/H2	Panasonic DMC-FZ50	S0/COLT2
Nikon Coolpix S4000	T1/H1/H0	Olympus Mju 6010	A3/H2	Panasonic DMC-FZ7	B2
Nikon Coolpix S500	H0T1	Olympus Mju 6020	T2/H2	Panasonic DMC-FZ8	B2
Nikon Coolpix S500	H1	Olympus Mju 7000	H2,T2	Panasonic DMC-G1K	COLT2
Nikon Coolpix S50C	H0	Olympus Mju 7000	H2/T2	Panasonic DMC-GF-1 14-55	B2/Colt1
Nikon Coolpix S510	A3/T1/H2	Olympus Mju 7010	H2/T1/A3	Panasonic DMC-GF-1 1,7/20	Colt0
Nikon Coolpix S51C	H0/A1	Olympus Mju 7040	T2/H2	Panasonic DMC-L10 14-50	S1
Nikon Coolpix S520	H0	Olympus Mju 720sw	H1/H0/T1	Panasonic DMC-LS75	H2
Nikon Coolpix S52C	H0	Olympus Mju 725 sw	H1/H0/T1	Panasonic DMC-LS80	H2/H4
Nikon Coolpix S560	A1,H2,T1	Olympus Mju 730	H2/H0	Panasonic DMC-LS85	A3,H2
Nikon Coolpix S570	A1,H1,T1	Olympus Mju 770SW	A1/H0/T1	Panasonic DMC-LX1	H4
Nikon Coolpix S600	H1/A1/T1	Olympus Mju 780	H2/T1	Panasonic DMC-LX2	H4
Nikon Coolpix S610	H2	Olympus Mju 790 SW	H0	Panasonic DMC-LX3	B1/Colt0
Nikon Coolpix S610C	H2	Olympus Mju 8010	T2/H2	Panasonic DMC-LX5	B1A
Nikon Coolpix S620	H1,T1	Olympus Mju 840	H0	Panasonic DMC-LZ10	H2
Nikon Coolpix S630	HE	Olympus Mju 9000	H2,T2	Panasonic DMC-LZ6	A2
Nikon Coolpix S640	A1,H1,T1	Olympus Mju 9000	H2/T2	Panasonic DMC-LZ8	H2
Nikon Coolpix S70	H0	Olympus Mju 9010	T2/H2	Panasonic DMC-TZ10	H4, A4, T2
Nikon Coolpix S700	A3/T1/H2	Olympus Pen E-P1 14-42	B2	Panasonic DMC-TZ2,TZ3	A4/H3/T2
Nikon Coolpix S710	H2	Olympus Pen E-P1 17mm	Colt0	Panasonic DMC-TZ4 TZ5	H3/T27A4
Nikon Coolpix S7C	H0	Olympus Pen EPL1 14-42	B2/Colt1	Panasonic DMC-TZ6,TZ6	H3/T27A4
Nikon Coolpix S8000	T2	Olympus SP 510 UZ	B2	Panasonic DMC-TZ8,TZ10	H4, A4, T2
Nikon Coolpix S900	T1/H1/H0	Olympus SP 560	B1/U1	Panasonic DMC-ZX-1 ZX-3	A3/H2
Nikon D200 18-55	S1	Olympus SP 565 UZ	COLT1	Pentax ist D 18-55	S0
Nikon D300 S 18-105	S1	Olympus SP 570 UZ	COLT1/B2	Pentax ist DL18-55	S0
Nikon D3000 18-55	S0/Colt2	Olympus SP 590UZ	COLT1	Pentax ist DS 2 18-55	S0
Nikon D40X 18-55	S0/Colt2	Olympus SP600	COLT1	Pentax K-7 mit 18-55	Colt2/S0
Nikon D50 18-55	S1	Olympus SP800	COLT1	Pentax K-X mit 18-55	S0/COLT2
Nikon D5000 18-55	S0/Colt2	Panasonic DMC-F56	H2/T1	Pentax K10 d 18-55	S0
Nikon D60 18-55	S0/Colt2	Panasonic DMC-F62	H2/T1	Pentax K110 d 18-55	S0
Nikon D60 18-55	S1	Panasonic DMC-FP8	A1/H0	Pentax K200D	S1
Nikon D80 118-55	S1	Panasonic DMC-FS10	H0/T1	Pentax K20D	S1
Nikon D90 18-105	Colt3	Panasonic DMC-FS11	H0/T1	Pentax KM mit 18-55	COLT2/S0
Nikon D90 18-55	S0/	Panasonic DMC-FS25	H0,A1	Pentax Optio E90	H2/T1
Olympus E30 12-60	Colt3	Panasonic DMC-FS30	H2	Pentax Optio H90	H2
Olympus E300 14-45	S1	Panasonic DMC-FS33	H2	Pentax Optio I10	T2/H4/A4
Olympus E330 14-45	S1	Panasonic DMC-FS62	T1/H2	Pentax Optio M30	H0/H1
Olympus E410 mit 14-42	S0	Panasonic DMC-FS7	H0/T1	Pentax Optio M40	H0/T1
Olympus E450 mit 14-42	S0/Colt2	Panasonic DMC-FT-1	H2	Pentax Optio M50	H0/T1
Olympus E500 mit 14-42	S0	Panasonic DMC-FX10	H1/A1/T1	Pentax Optio P70	H0/T1/A1
Olympus E510 mit 14-42	S0	Panasonic DMC-FX100	H2/T1	Pentax Optio P80	H0,A1,T2
Olympus E520 mit 14-42	S0	Panasonic DMC-FX12	H1/A1/T1	Pentax Optio S12	H1/A1/T1
Olympus E620 mit 14-42	S0/Colt2	Panasonic DMC-FX150	H2/T1/A3	Pentax Optio S50	H2/A3
Olympus FE 250	H0/H1/A1	Panasonic DMC-FX30	H0/A3/T1	Pentax Optio S55	H2

Pentax Optio S60	H2/A3	Samsung Digimax SL202	H1/A1/T1	Sony DSC-H55	T1/H1/A1
Pentax Optio S7	H1	Samsung Digimax SL420	A3/H2	Sony DSC-H7	B2/U1
Pentax Optio SVi	H2/A3	Samsung Digimax St100	H2	Sony DSC-H9	B2/U1
Pentax Optio V10	H0/H1	Samsung Digimax ST80	H1	Sony DSC-HX1	COLT1
Pentax Optio W60	H2/A4	Samsung Digimax TL100	H0/T1	Sony DSC-HX5VN	T2/A4/H2
Pentax Optio W80	H2/A4	Samsung Digimax WB2000	A4	Sony DSC-S210	H2
Pentax Optio W90	H2/A4	Samsung DigimaxST600	H2/T2	Sony DSC-S2100	H2
Pentax Optio WS80	T1/H1/A1	Samsung ES65	T1/H2	Sony DSC-S750+S780	H1/T1
Pentax Optio X70	B2, COLT1	Samsung ES70	T1/H2	Sony DSC-S800	H2
Pentax Optio x90	Colt1	Samsung EX1	COLT0	Sony DSC-S800	H2
Pentax Optio Z10	A3/H2/T1	Samsung GX10 10-17	S1	Sony DSC-T33	A1/H1
<b>Ricoh CX1,CX2,CX3,CX4</b>	<b>H4/A4/T2</b>	Samsung NX10 mit 18-55	COLT2/S0	Sony DSC-T50	H0/H2/A3
<b>Ricoh CXR mit A12</b>	<b>B2</b>	Samsung NX10 mit 30mm	COLT1	Sony DSC-T500	H0
<b>Ricoh CXR mit S10</b>	<b>B2</b>	Samsung ST 45	H0/T1	Sony DSC-T7	A1
<b>Ricoh GR digital</b>	<b>H3/A4</b>	Samsung ST1000	H0/A3	Sony DSC-T70	H0/A1
<b>Ricoh GR digital+Zubehör</b>	<b>B1</b>	Samsung ST500	H2	Sony DSC-T700	A1/H0/T1
<b>Ricoh GX200 +DW6</b>	<b>B2</b>	Samsung ST5000	T2/H2/A4	Sony DSC-T77	H0
<b>Ricoh R8, R10</b>	<b>T2/A4/H4</b>	Samsung ST550	H2	Sony DSC-T9	A1/H0
Samsung Digimax ES15	H2	Samsung ST60	T1/H1/A1	Sony DSC-T90	H0/T1
Samsung Digimax ES20	A2/H2	Samsung WB1000	H2	Sony DSC-T900	H0
Samsung Digimax ES55	H2	Samsung WB500	T2	Sony DSC-TX1	A1/H0
Samsung Digimax ES65	T1/H2	Samsung WB550	T2	Sony DSC-TX5	H0/T1
Samsung Digimax ES75	H2/T1	Samsung WB600	T2/H4/A4	Sony DSC-TX7L	H0
Samsung Digimax FL820	H2	Samsung WB650	T2/H4/A4	Sony DSC-TX9	H0
Samsung Digimax GX1L	S0	<b>Sanyo VPC-E6</b>	<b>H2</b>	Sony DSC-TX99	H0
Samsung Digimax GX1S	S0	<b>Sanyo VPC-E60</b>	<b>H2</b>	Sony DSC-W130	H1/A1/T1
Samsung Digimax HZ10W	H4/H3/A2/T2	<b>Sanyo VPC-J4</b>	<b>H2/A2</b>	Sony DSC-W150	H1/A1/T1
Samsung Digimax HZ15W	H4/A2/T2	<b>Sanyo VPC-MZ3</b>	<b>A2</b>	Sony DSC-W180	H0/T1
Samsung Digimax L201	H0/A1/T1	<b>Sanyo VPC-S3</b>	<b>H2/A2</b>	Sony DSC-W200	A17T1
Samsung Digimax L50	H2/A3	<b>Sanyo VPC-S6</b>	<b>H2/A3</b>	Sony DSC-W210	H2/T1
Samsung Digimax L70	H0/T1	<b>Sanyo VPC-S60</b>	<b>H2/A3</b>	Sony DSC-W215	H2/T1
Samsung Digimax L700	H0/A3/T1	Sigma SD 10 mit 18-200	S1	Sony DSC-W220	H1,A1,T1
Samsung Digimax L77	H2/A3/T1	Sigma SD 14 mit 18-200	S1	Sony DSC-W230	H2,T1
Samsung Digimax L83T	H0/A2	Sigma SD 15 mit 18-200	S1	Sony DSC-W270	A3/H2
Samsung Digimax LZ4	H0	<b>Sony a 230 mit 16-105</b>	<b>Colt3</b>	Sony DSC-W290	H2/A3
Samsung Digimax NV 24 HD	H2/A3	<b>Sony a 230 mit 18-70</b>	<b>S0/Colt2</b>	Sony DSC-W30	H2/A3/T1
Samsung Digimax NV10	H0	<b>Sony a 290 mit 18-55</b>	<b>S0/COLT2</b>	Sony DSC-W300	H2/T1
Samsung Digimax NV100HD	H2/A3	<b>Sony a 300 mit 18-70</b>	<b>S0/Colt2</b>	Sony DSC-W310	T1/A1
Samsung Digimax NV11	H2	<b>Sony a 33 mit 18-55</b>	<b>S0/COLT2</b>	Sony DSC-W320	T1/H1/A1
Samsung Digimax NV15	H2/A3	<b>Sony a 350 mit 18-70</b>	<b>S0/Colt2</b>	Sony DSC-W350	T1/H1/A1
Samsung Digimax NV20	H2/A3	<b>Sony a 380 mit 28-75 Sam</b>	<b>Colt3</b>	Sony DSC-W360	T1/H1/A1
Samsung Digimax NV3	H0	<b>Sony a 390 mit 18-55</b>	<b>S0/COLT2</b>	Sony DSC-W360	T1/H1/A1
Samsung Digimax NV30	H2/T1	<b>Sony a 450 mit 50 Sam</b>	<b>S0</b>	Sony DSC-W380	H1/A3/T1
Samsung Digimax NV8	H2/A4	<b>Sony a 500 mit 18-55</b>	<b>Colt2/S0</b>	Sony DSC-W50,	H2/A3/T1
Samsung Digimax NV9	H2/A1	<b>Sony a 55 mit 18-55</b>	<b>S0/COLT2</b>	Sony DSC-W70	H2/A3/T1
Samsung Digimax PL10	H0/A1	<b>Sony a 550 mit 18-70</b>	<b>Colt2/S0</b>	Sony DSC-WX1	H2/T1
Samsung Digimax PL100	T1/H2	<b>Sony a 560 mit 18-55</b>	<b>COLT2</b>		
Samsung Digimax PL150	H2/A3	<b>Sony a 580 mit 18-55</b>	<b>COLT2</b>		
Samsung Digimax PL200	A4	<b>Sony a 700 mit 1,4/85</b>	<b>S1</b>		
Samsung Digimax PL50	T1/H2	<b>Sony DSC-G1</b>	<b>T2</b>		
Samsung Digimax PL51	H2/T1	<b>Sony DSC-H10</b>	<b>B</b>		
Samsung Digimax PL55	H2	<b>Sony DSC-H2</b>	<b>B2/U1</b>		
Samsung Digimax PL65	H2	<b>Sony DSC-H20</b>	<b>Colt0</b>		
Samsung Digimax PL70	H2	<b>Sony DSC-H3</b>	<b>T2</b>		
Samsung Digimax PL80	H2	<b>Sony DSC-H5</b>	<b>B2/U1</b>		
Samsung Digimax PL90	H0	<b>Sony DSC-H50</b>	<b>COLT1</b>		
Samsung Digimax S1000	H2				
Samsung Digimax S1050	A2/H4				
Samsung Digimax S750	H4/T2				



DIGITAL+PHOTO+MORE

[www.digiETUI.de](http://www.digiETUI.de)  
[info@digiETUI.de](mailto:info@digiETUI.de)